


# ASSEMBLY INSTRUCTIONS



### ASSEMBLY TIPS








1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast and easy assembly.











### Warning !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.

### HARDWARE LIST

1		8 PCS	5		14 PCS
JCBC M6 x 100mm		14 PCS		WOOD DOWEL Ø10 x 30mm	22 PCS
2		6 PCS	6		1 PC
JCBB M6 x 80mm		6 PCS		BARREL NUT M6 x 16mm	1 PC
3		12 PCS	7		
JCBC-W M6 x 30mm		12 PCS		ALLEN KEY M4	
4					
WOOD SCREW 4.0 x 30mm					

### COMPONENT LIST

A		1 PC	F		1 PC
FRONT LEG - LEFT		1 PC		BACK PANEL	
B		1 PC	G		2 PCS
FRONT LEG - RIGHT		1 PC		SIDE RAIL	2 PCS
C		1 PC	H		1 SET
BACK LEG - RIGHT		1 PC		SLAT	1 SET
D		2 PCS			
BACK LEG - LEFT		2 PCS			
E					
HEADBOARD/FOOTBOARD PANEL					

