



ASSEMBLY INSTRUCTIONS /
INSTRUCTIONS D'ASSEMBLAGE

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004



PARTS IDENTIFICATIONS /
IDENTIFICATION DES PIECES

























ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004



(1)	1pc	(9)	1pc	(17)	1pc
(2)	1pc	(10)	1pc	(18)	1pc
(3)	1pc	(11)	1pc	(19)	1pc
(4)	1pc	(12)	1pc	(20)	1pc
(5)	1pc	(13)	1pc	(21)	2pcs
(6)	1pc	(14)	2pcs	(22)	2pcs
(7)	2pcs	(15)	1pc	(23)	1pc
(8)	1pc	(16)	1pc	(24)	1pc


HARDWARE IDENTIFICATIONS/
IDENTIFICATION DU KIT D'ASSEMBLAGE

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004


A		L29	33pcs
B		ø15	33pcs
C		ø8 x 25	27pcs
D		ø4 x 30	8pcs
E		L20	4pcs
F		ø12	4pcs
G		96#	2pcs
H		ø4x22	4pcs
I		ø6 x 30	4pcs
J		ø4 x 35	2pcs
K		ø4 x 25	4pcs
L		ø6 x 65	2pcs
M		ø10x15	2pcs
N		ø7 x 48	8pcs
O			50pcs
P		M4	1pc
Q			1pc
R			1pc
S		ø8	1pc
T		ø3 x 16	2pcs
U		ø3 x 14	2pcs
V		ø20	10pcs
W		ø16	6pcs
X		Glue: For securing please apply to wood dowel first before inserting into panel	1pc

ASSEMBLY INSTRUCTION

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004




STEP 1



STEP 2

STEP 3




ASSEMBLY INSTRUCTION


ITEM NO/NO ARTICLE: TV stand/Meuble TV

172000 172004


STEP 4



STEP 5




STEP 6




ASSEMBLY INSTRUCTION

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004



STEP 7


STEP 8



PAGE: 6 OF 11


ASSEMBLY INSTRUCTION

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004




STEP 9

STEP 10




ASSEMBLY INSTRUCTION

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004




STEP 11

STEP 12




ASSEMBLY INSTRUCTION

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004




STEP 14




ASSEMBLY INSTRUCTION

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004



STEP 15

STEP 16



ASSEMBLY INSTRUCTION

ITEM NO/NO ARTICLE: TV stand/Meuble TV
172000 172004

