



ASSEMBLY INSTRUCTIONS / INSTRUCTIONS D'ASSEMBLAGE

ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686



PARTS IDENTIFICATIONS / IDENTIFICATION DES PIECES


























ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686



(1)	1pc	(7)	2pcs	(13)	1pc
(2)	1pc	(8)	1pc	(14)	1pc
(3)	2pcs	(9)	1pc	(15)	1pc
(4)	1pc	(10)	1pc	(16)	1pc
(5)	1pc	(11)	1pc	(17)	1pc
(6)	1pc	(12)	4pcs	(18)	1pc


HARDWARE IDENTIFICATIONS/ IDENTIFICATION DU KIT D'ASSEMBLAGE

ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686

A		L29	16pcs
B		ø15	16pcs
C		L20	4pcs
D		ø12	4pcs
E		ø8x25	14pcs
F		ø6x30	2pcs
G		ø3 x 14	4pcs
H		ø3 x 16	4pcs
I		ø4x30	6pcs
J		ø4x45	4pcs
K			2pcs
L			2pcs
M			2pcs
N		M6x12	2pcs
O			42pcs
P		ø22	16pcs
Q		ø16	4pcs
R		ø5	8pcs
S		M8x35	4pcs
T		ø16xø8x2	4pcs
U		M5	1pc
V			3pcs
W		M4x22	6pcs
X		80x25x120	1pc
Y			1pc


Glue: For securing please apply to wood
dowel first before inserting into panel

ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686




STEP 1 / ETAPE 1

STEP 2 / ETAPE 2




ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686




STEP 3 / ETAPE 3

STEP 4 / ETAPE 4




ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686




STEP 5 / ETAPE 5

STEP 6 / ETAPE 6




ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686




STEP 7 / ETAPE 7

STEP 8 / ETAPE 8




ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686




STEP 9 / ETAPE 9


STEP 10 / ETAPE 10





ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686



STEP 12 / ETAPE 12



ITEM NO/NO ARTICLE: TV stand/Meuble TV
192610 202686



STEP 13 / ETAPE 13

STEP 14 / ETAPE 14

